

Dell™ UPS Management Software

Installation and Configuration User's Guide

Notes



NOTE: A NOTE indicates important information that helps you make better use of your software.

Information in this document is subject to change without notice.

© 2009–2010 Dell Inc. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell* and the *DELL* logo are trademarks of Dell Inc.; *Hyper-Vis* is a trademark and *Microsoft*, *Windows*, *Windows Server*, and *Windows Vista* are registered trademarks of Microsoft Corporation; *Linux* is a registered trademark of Torvalds; *Red Hat* is a registered trademark of Red Hat, Inc.; *SUSE* is a registered trademark of Novell, Inc.; *Ubuntu* is a registered trademark of Canonical Ltd. *VMware* is a registered trademark of VMware, Inc.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

Table of Contents

1	Introduction	
	Dell UPS Management Software Components	6
	Dell UPS Management Software Applications	8
	Features	10
2	Installation	
	System Requirements	11
	Installing the Software	12
	Installing in a GUI Environment	12
	Installing in a Console Environment	20
	Starting the Software	20
	Software Startup in a Microsoft Windows Operating System	20
	Software Startup in a Linux Operation System	21
	Uninstalling the Software	22
	Uninstalling in a Microsoft Windows Operating System	22
	Uninstalling in a Linux Operating System	26
3	About the Software	
	The Dell UPS Management Software Window	27
	Setting Software Preferences	29
	Changing the Window Appearance	29
	Changing the Date Format	31
	Changing Advanced Settings	32
	Changing Languages	34

4 Configuring the Software

Auto-Searching the UPS	36
Modifying the Password	39
Viewing the Event Log	41
Viewing the Data Log	42
Setting Event and Data Log File Parameters	43
Configuring Event Actions	44
Broadcasting a Message	46
Sending Event Messages by E-Mail	49
Sending Event Messages by Mobile Phone	55
Sending Event Messages by Pager	57
Resetting the Dell UPS Sensor Values	60
Setting up UPS Load Segment Control	61
Renaming the UPS Model	62
Configuring Shutdown Parameters	63
Remote Shutdown by Agent	65
Shutdown Remote Agents	66
Shutdown Devices Monitored by Network Management Card	68
Redundant UPS Shutdown	69
Entering the UPS Warranty Period	70
Testing the UPS	73
Performing a UPS Self-Test Immediately	73
Scheduling a UPS Self-Test	74
Changing a Scheduled UPS Self-Test	77
Removing a Scheduled UPS Self-Test	78
Turning the UPS On/Off	79
Scheduling a UPS On/Off Task	79
Changing a Scheduled UPS On/Off Task	82
Removing a UPS On/Off Task	83

Viewing Scheduled Tasks	84
Remotely Controlling a UPS on the LAN or Internet	85
Monitoring a UPS through SNMP	89
Rebooting Computers after a Utility Failure	96
Exporting Configuration Parameters	97
5 Event Descriptions	
6 Installation on a VMware ESX Server	
Installation	105
Prerequisites	105
Dell UPS Management Software Installation	105
Installing VMware Tools on a Microsoft Windows Guest	106
Installing VMware Tools on a Linux Guest	109
Configuration	112
VMware Server Configuration	112
Communication Through an RS-232 or USB Port	113
Communicating Through the Network Management Card	115
7 Installation on a VMware ESXi Server	
Installation and Configuration	119
Prerequisites	119
vMA Installation	119
vMA Configuration	120
VMware ESXi Server Configuration	120
Installing VMware Tools on a Microsoft Windows Guest Operating System	121
Installing VMware Tools on a Linux Guest Operating System	124
VIMA/vMA Shutdown and Startup Configuration	127
Dell UPS Management Software Installation	129
Shutdown Parameter Setting for Network Management Card	130
Dell CUI Commands List	133

Introduction

Dell™ UPS Management Software supports either an individual computer or network-connected computers [including both local area networks (LANs) and the Internet].

The software monitors the UPS and safeguards computer systems from uncontrolled shutdowns due to power failure. With the Dell UPS Management Software, you can monitor and configure the UPS on any computer within the same LAN. One UPS can provide multiple computers in a network with simultaneous power management, including system shutdown, saving application data, and shutdown of the UPS when utility power fails.



Dell UPS Management Software Components

Dell UPS Management Software has three components:

- **The Agent** is the core component of the Dell UPS Management Software and runs in the background as a system service. It communicates with the UPS, logs events, notifies users of events, arranges actions according to the user's specifications, and initiates shutdown when necessary. The Agent can be managed by the Monitor.
- **The Monitor** is the user interface application of the Dell UPS Management Software. Relying on the Agent, it gathers real-time UPS information, UPS status, and server information, and allows the user to tailor the UPS working parameters. The Monitor can run on any computer on the LAN or on a standalone computer.
- **The Tray Icon** is the management tool of the Dell UPS Management Software, and it appears in the status area of the system task bar. The Tray Icon is available only for the Microsoft® Windows® platform.

The Tray Icon uses two different icons to display the current Agent status (see Table 1):

Table 1. Tray Icon

	Agent is running.
	Agent is stopped.

Right click the Tray Icon to display a shortcut menu (see Figure 1). Use the shortcut menu to start and stop the Agent or Monitor.



Figure 1. Tray Icon Shortcut Menu

Figure 2 shows the relationships between the software components and the UPS.




Figure 2. Relationship Between Software Components and UPS

Dell UPS Management Software Applications

Figure 3 shows the software application with a standalone computer.




Figure 3. Standalone Computer Application

Figure 4 shows the software application with a LAN.




Figure 4. LAN Software Application

Figure 5 shows the software application with the Internet.




Figure 5. Internet Application

Features

The Dell UPS Management Software has the following features:

- Runs continuously to protect the equipment after the Agent starts.
- Uninstalls easily and completely.
- Provides a panoramic view of all information, including utility power, UPS, load, and battery status, all in the same window.
- Automatically searches and remotely monitors any Dell UPS on the LAN.
- Manually searches and remotely monitors any Dell UPS on the Internet.
- Provides security protection with an administrator password. Only the system administrator has full access; other users have only view access.
- Protects data automatically by closing open applications and saving the related files.
- Turns the UPS on and off, providing maximum protection for your computer system.
- Initiates a UPS self-test.
- Supports Simple Network Management Protocol (SNMP) monitoring.
- Shuts down the network.
- Logs data and events (including utility power, UPS, load, and battery status) so the system administrator can perform daily system maintenance.
- Provides flexible methods of notifying users of UPS status, including:
 - Broadcasting messages to all users in the network.
 - Sending messages to a pager.
 - Sending messages by e-mail.
 - Sending messages to a mobile phone with Short Message Service (SMS).

Installation

System Requirements

- A minimum of 128 MB of physical memory (256 MB is recommended)
- A minimum of 160 MB of hard disk space
- More than 256 colors and 800 x 600 resolution or above display is recommended
- Administrator credentials (for Microsoft Windows Vista® and Windows 7 operating systems)
- Superuser credentials for Linux® operating systems
- TCP/IP communication protocol installed to support network management
- An available communication port (RS-232 serial port or USB port)

Platforms supported by Dell UPS Management Software include:

- Microsoft Windows Server® 2008, Standard Edition
- Microsoft Windows Server 2008, Standard x64 Edition (includes Hyper-V™)
- Microsoft Hyper-V Server 2008 R2
- Microsoft Windows Storage Server 2008, Standard Edition
- Microsoft Windows Server 2003 R2, Standard Edition
- Microsoft Windows Server 2008 R2, Standard x64 Edition
- Microsoft Windows Small Business Server 2003 R2
- Microsoft Windows Small Business Server 2008
- Red Hat® Enterprise Linux
- Novell® SUSE® Linux Enterprise Server
- Microsoft Windows XP® Professional
- Microsoft Windows XP Home
- Microsoft Windows Vista Home Premium
- Microsoft Windows Vista Business
- Microsoft Windows Vista Ultimate
- Microsoft Windows 7 Professional x32, x64
- Microsoft Windows 7 Ultimate
- Ubuntu® Linux

Installing the Software

This section includes installation instructions in a graphical user interface (GUI) environment and a console environment.


Installing in a GUI Environment

To install the software in a GUI environment:

- 1 For a Microsoft Windows operating system, run `setup.exe` from the **CD drive: \Windows** directory to start the installation program (see Figure 6).



Figure 6. Setup Icon

 **NOTE:** In the Microsoft Windows Vista and Windows 7 operating systems, you are prompted to enter the administrator account information.

For other operating systems, enter the command:

```
./setup.bin
```

or

```
setup_console.bin
```

 (see Figure 7).

Figure 7. setup.bin

- 2 Select the language for the software and click **OK** (see Figure 8).




Figure 8. Selecting the Language for Installation

- 3 Read the introduction and click **Next** (see Figure 9).




Figure 9. Introduction Window

- 4 If there is a previously installed version of the Dell UPS Management Software, the software prompts you to remove it. Click Yes to remove the software and continue with the installation (see Figure 10).




Figure 10. Removing the Previous Software Version

- 5 The software provides an option to keep the previous software configuration parameters, such as local UPS information, Network Management Card settings, shutdown parameters, and alarm settings. Click Yes to keep the previous configuration file; otherwise, click No.




Figure 11. Saving the Previous Configuration Parameters

The software begins uninstalling the software (see Figure 12).




Figure 12. Uninstalling the Software

- 6 By default, the software installs to C:\Program Files\Dell\UPS Management Software. Update the location if needed and click Next (see Figure 13).




Figure 13. Choose Install Folder Window

7 Select the shortcut folder and click Next (see Figure 14).




Figure 14. Choose Shortcut Folder Window

- Review the selected installation options. If the options are correct, click **Install** to begin the installation (see Figure 15).




Figure 15. Pre-Installation Summary Window

The Installing window displays (see Figure 16).




Figure 16. Installing Window

9 When the installation program is complete, click **Done** to exit the installer (see Figure 17).




Figure 17. Install Complete Window

If the software installed successfully, the Dell UPS Management Software application can be found in **All Programs** from the **Start** menu (see Figure 18).



Figure 18. Dell UPS Management Software Application in the Start Menu

Installing in a Console Environment

To install the software in a console environment:

- 1 To start the installation program, enter the directory appropriate for the system and enter the command:

```
setup_console.bin
```

- 2 Read the provided information and press **Enter** to continue the installation.
- 3 Review the selected installation options. If the options are correct, click **Install** to begin the installation.
- 4 When the installation program is complete, click **Done**.
- 5 Reboot the system to activate the software.

The installation program stores the Dell UPS Management Software run environment variables in `/etc/profile`.

Starting the Software

This section includes startup instructions for Microsoft Windows and Linux operating systems.

Software Startup in a Microsoft Windows Operating System

To start the software in a Microsoft Windows operating system:

- 1 Start the Agent using one of the following methods:
 - Set the Agent to start automatically at computer startup.
 - Select **Start menu > All Programs > Dell UPS Management Software** to start the Tray Icon and Agent (see Figure 19).




Figure 19. Starting the Tray Icon and Agent

- 2 Start the Monitor. Right click the Dell UPS Management Software Tray Icon and select Start Monitor (see Figure 20).




Figure 20. Starting the Monitor

- 3 For Microsoft Windows Vista, Windows 7, and Windows Server 2008 operating systems, complete Steps 4 and 5.
- 4 Right click the Dell UPS Management Software Tray Icon and select Exit.
- 5 Restart the computer to restart the Dell UPS Management Software.

If you have administrator privileges, you can restart the Dell UPS Management Software without restarting the computer:

- To start the Agent, select **Start menu > Control Panel > Administrative tools > Services**, and find the service UPSMSmonitor. Right click UPSMSmonitor and select **Start**.
- To start the Tray Icon, select **Start menu > All Programs > Dell UPS Management Software**.

Software Startup in a Linux Operation System

To start the software in a Linux operating system:

- 1 The Agent starts automatically at system boot. If not already started, from the `/opt/UPS` directory, enter the command:

```
./agent start
```

- 2 Start the Monitor. From the `/opt/UPS` directory, enter the command:

```
./monitor
```

Uninstalling the Software

This section includes uninstall instructions for Microsoft Windows and Linux operating systems.

Uninstalling in a Microsoft Windows Operating System

To uninstall the software in a Microsoft Windows operating system:

- 1 Exit all Dell UPS Management Software programs.
- 2 Stop the Agent. Right click the Dell UPS Management Software Tray Icon and select **Stop Agent** (see Figure 21).




Figure 21. Stop Agent

- 3 Exit the software. Right click the Dell UPS Management Software Tray Icon and select **Exit** (see Figure 22).



Figure 22. Exit

- 4 Begin uninstalling the software one of the following ways:
 - Select Start menu > All Programs > Dell UPS Management Software > Uninstall Dell UPS Management Software (see Figure 23).




Figure 23. Uninstall Dell UPS Management Software

- Select Start menu > Control Panel > Add/Remove Program. Select the Dell UPS Management Software and click Change/Remove (see Figure 24).




Figure 24. Add or Remove Programs

5 The Uninstall Program window opens (see Figure 25). Click **Uninstall** to continue.




Figure 25. Uninstall Dell UPS Management Software Window

The uninstalling process begins (see Figure 26).




Figure 26. Uninstall Progress

- 6 After the Dell UPS Management Software uninstalls completely, click **Done** (see Figure 27).




Figure 27. Uninstall Complete Window

Uninstalling in a Linux Operating System

To uninstall the software in a Linux operating system:

- 1 Stop the Agent. From the `/opt/UPS` directory, enter the command:

```
./agent stop
```
- 2 Open the Terminal and enter the `/opt/UPS` directory.
- 3 Enter the command:

```
./Uninstall
```

About the Software

This chapter describes the Dell UPS Management Software window and how to set preferences for the software.

The Dell UPS Management Software Window

Select **Start Monitor** from the **Tray Icon** or select **Dell UPS Management Software** from the program list to open the Dell UPS Management Software window, which displays a list of all Agents within the LAN.

The tree view on the left side of the window displays a hierarchical list of items, such as Root, network names, SNMP, the Agents, the communication port, and the UPS models (see Figure 28). By clicking an item, you can expand or collapse the associated list of sub-items.




Figure 28. Dell UPS Management Software Window

Selecting one of the UPS models displays details about the UPS on the right side of the window (see Figure 29).

The UPS status diagram is a graphical representation of the UPS power status. The diagram shows the AC Line, UPS, Load, Battery, and Bypass (if the UPS is on bypass). The data boxes for both the UPS and Load have multiple pages. Click the data table to go to the next page.

The UPS state displays at the top of the window.

The last two events display at the bottom of the window.




Figure 29. Data Boxes with Multiple Pages

Setting Software Preferences

You can customize the window appearance, specify the date format, and select a local language.

Changing the Window Appearance

Select **Background Image** from the **Preferences** menu to change the appearance of the main window (see Figure 30).




Figure 30. Changing the Appearance

You can select one of the following for the background of the main window:

- **None:** Default gray background.
- **Color:** Uniform color background.
- **Gradient:** One color from light to dark.
- **Text:** Repeating text.
- **Grid:** Repeating image.
- **Picture:** Single image.

For example (as shown in Figure 31), select **Color** to change the background from the default gray to the color defined in the Advanced Settings.

You can customize your selection of the background (see “Changing Advanced Settings” on page 32).




Figure 31. Changing the Background Color

Changing the Date Format

Select **Date Format** from the **Preferences** menu to change the date format. The date options are: Year/Month/Date, Month/Date/Year, or Date/Month/Year (see Figure 32).




Figure 32. Changing the Date Format

Changing Advanced Settings

Select **Advanced Settings** from the **Preferences** menu. The **Advanced Settings** window opens (see Figure 33).






Figure 33. Advanced Settings Window – General Tab

Use the Advanced Settings window to change the appearance of the interface text and customize the selected background image.

On the Advanced Settings – General tab view, you can change the color of the regular text and the warning text. You can also change the font and text size from the Font lists (see Figure 33).

On the Advanced Settings – Background Image tab view, you can select and customize the image background.

 **NOTE:** To add pictures to the Picture drop-down list box, paste the image file in the images folder. The default folder location is C:\Program Files\Dell UPS SW\images.

 **NOTE:** Clicking the Default button returns the parameters to the default values.




Figure 34. Advanced Settings Window – Background Image Tab

Changing Languages

To change the language of the interface display text, select the **Language** menu and then one of the languages: **English**, **Traditional Chinese**, **Simplified Chinese**, **German**, **French**, **Spanish**, **Russian**, **Japanese**, or **Korean** (see Figure 35).





Figure 35. Selecting the Language for the Interface

Configuring the Software

 **NOTE:** You must log in as administrator through the System menu to change any settings or the settings will not be saved or implemented.

This chapter explains how to:

- Auto-search for a UPS
- Modify the password
- View and set up the Event Log and Data Log
- Configure actions for events, such as broadcasting a message, e-mailing a message, sending a text message, or sending a page
- Reset the Dell UPS sensor values
- Control the UPS load segments
- Rename the UPS model
- Configure shutdown parameters
- Set the UPS warranty period
- Perform and schedule a UPS self-test
- Perform and schedule a UPS on/off task
- Remotely monitor any Dell UPS within the same LAN or on the Internet
- Reboot computers on the LAN
- Export configuration parameters

Auto-Searching the UPS

Click **Auto Search UPS** from the **System** menu to search for the UPS connected to the computer's serial port (see Figure 36). The search result displays in the tree view (see Figure 37).




Figure 36. System Menu





Figure 37. Search Results

Clicking an item in the tree view displays the following information (see Figure 38):

- All computers in the LAN that are running the Dell UPS Management Software Agent.
- The UPS communication port.
- The model type of the UPS to which the Agent is connected.
- The current status of the selected Agent.

 **NOTE:** Select a UPS model to display details about the UPS (see Figure 29 on page 28).





Figure 38. Details of Selected Tree View Item

 **NOTE:** The first time the Agent starts requires more time than subsequent startups to communicate with the UPS. The software keeps a record of UPS information and, after the first startup, the software starts according to the last record. If the COM port, USB port, UPS model, or IP address changes, click Auto Search UPS from the System menu to retrieve the new UPS information.

For Linux platforms, the software cannot auto-detect the serial port devices. If the system has a serial port not listed in the default setting table, you must add it manually. Table 2 shows the default serial port device settings.

Table 2. Default Serial Port Device Settings

Platform	Serial Port Device
Linux	/dev/ttyS0 /dev/ttyS1

To manually add a serial port:

- 1 Select **COM Port Setting** from the **System** menu.

The Communication Port Settings window opens (see Figure 39).




Figure 39. Communication Port Settings Window


- 2 Enter the serial port device setting and click **Add**.
- 3 Click **OK** to save and exit.

To remove a communication port, select the device name and click **Remove**.

Modifying the Password

To modify the password:

- 1 Log in as the administrator.
- 2 Select **Act as Administrator** from the **System** menu. Enter the administrator password and click **OK** (see Figure 40).

 **NOTE:** The default password is **admin**.




Figure 40. Administrator Password

If the password is not correct, the system displays an error message (see Figure 41).



Figure 41. Error Message

- 3 Select **Modify Administrator Password** from the **System** menu. The Administrator Password Settings window opens (see Figure 42).




Figure 42. Administrator Password Settings Window




NOTE: Only a Superuser on a local machine can set the administrator password. If you are not a Superuser, the Administrator window opens first, prompting you to log in as an administrator.

- 4 Enter a new password in the **New Password** field.
- 5 Reenter the new password in the **Confirm Password** field.
- 6 Click **OK**.
- 7 If the password is not the same, an error message displays. Reenter the password in both fields and click **OK**.

Viewing the Event Log

The Event Log Viewer displays the UPS event history (see Figure 43).

You can view the Event Log one of the following ways:

- Select **Event Log** from the **Logs** menu.
- Click the  icon from the toolbar.
- Click the **View Log** button in the Event Log area of the **Record Setting** window (see Figure 45 on page 43).





Figure 43. Event Log Viewer


Click the **Next**, **Prev**, **Home**, and **End** buttons to navigate to different pages. To remove selected Event Log items, select the Delete check box for each item and click **Delete**. To delete all events, click **Purge All**. To copy the log to a file, click **Export**. Click **Close** to exit the window.

Viewing the Data Log

The Data Log Viewer displays UPS data records (see Figure 44).

You can view the Data Log one of the following ways:

- Select **Data Log** from the **Logs** menu.
- Click the  icon from the toolbar.
- Click the **View Log** button in the Data Log area of the **Record Setting** window (see Figure 45).



The screenshot shows the Data Log Viewer window with a table of UPS data records. The window title is "Data Log Viewer" and it has a close button in the top right corner. The window contains a table with columns: DATE, TIME, Port, Model, IN-V, OUT-V, BATT-V, IN-F, LOAD, and DELETE. The table displays 15 records for the date 2009/03/25, all from a USB port, connected to a Dell UPS Rack 4200W High Efficiency Online. The IN-V and OUT-V values are 228 and 230 respectively, BATT-V is 220.0, IN-F is 49.8, and LOAD is 0. Each record has a checkbox in the DELETE column. Below the table are buttons for Next, Prev, Home, End, Delete, Purge All, Export, and Close. The record number is 1 - 15 / 388.

DATE	TIME	Port	Model	IN-V	OUT-V	BATT-V	IN-F	LOAD	DELETE
2009/03/25	09:34:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:36:52	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:38:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:37:52	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:38:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:39:52	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:40:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:41:54	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:42:54	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:43:53	USB	Dell UPS Rack 4200W High Efficiency Online	229	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:44:53	USB	Dell UPS Rack 4200W High Efficiency Online	229	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:45:54	USB	Dell UPS Rack 4200W High Efficiency Online	229	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:46:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:47:53	USB	Dell UPS Rack 4200W High Efficiency Online	228	230	220.0	49.8	0	<input type="checkbox"/>
2009/03/25	09:48:53	USB	Dell UPS Rack 4200W High Efficiency Online	229	230	220.0	49.8	0	<input type="checkbox"/>

Figure 44. Data Log Viewer

Click the **Next**, **Prev**, **Home**, and **End** buttons to navigate to different pages. To remove selected Data Log items, select the Delete check box for each item and click **Delete**. To delete all data, click **Purge All**. To copy the log to a file, click **Export**. Click **Close** to exit the window.

Setting Event and Data Log File Parameters

Use the Record Setting window to set the parameters for the log files. Select **Record Setting** from the **Logs** menu. The Record Setting window opens (see Figure 45).




Figure 45. Record Setting Window


 **NOTE:** Clicking the Default button returns the parameters in this view to the default values. If the OK button is disabled, the current Agent is read-only, and you cannot set up the parameters. You may log in as a Superuser through the Act as Administrator menu.

Table 3 lists the log options and parameters.

Table 3. Log Options and Parameters

Parameter	Unit	Maximum Value	Minimum Value	Default Value
Maximum File Length (Event Log)	Rows	10,000	20	600
Maximum File Length (Data Log)	Rows	10,000	20	10,000
Record Interval	Seconds	3,600	1	60

The **View Log** buttons open the Event Log or Data Log. See “Viewing the Event Log” on page 41 or “Viewing the Data Log” on page 42 for more information.

The **Settings** button opens the Event Action window. See the following section, “Configuring Event Actions,” for more information.

Configuring Event Actions

Select **Event Action** from the **UPS** menu, or click the  icon from the toolbar, or click the **Settings** button in the Record Setting window. The Event Action window opens (see Figure 46).




Figure 46. Event Action Window

You can select which actions should be performed when specific events occur:

- **Record** – Select the events to be recorded in the Event Log and select the Record check box. All events can be recorded in the Event Log.
- **PC Beep** – Select the events to initiate an audible beep on your computer and select the PC Beep check box. Only these events can be configured: Communication Lost, On Bypass, AC Fail, UPS Battery Low, and UPS Output Overload. The PC Beep feature is available only for Microsoft Windows platforms.

- **Pop-up warning** – Select the events to open a message window on your computer and select the Pop-up warning check box. Only these events can be configured: UPS Battery Low, Communication Lost, Communication Established, On Bypass, AC Fail, AC Restore, System to be shut down, System to be shut down by another Agent, and Warranty Period has expired. The Pop-up Warning feature is available only for Microsoft Windows platforms.
- **Broadcast** – Select the events to be broadcast to the configured users and select the Broadcast check box. All events can be broadcast. Continue to “Broadcasting a Message” on page 46 to complete the configuration.
- **E-mail** – Select the events to send an e-mail to the configured recipients and select the E-Mail check box. All events can be e-mailed. Continue to “Sending Event Messages by E-Mail” on page 49 to complete the configuration.
- **Send SMS** – Select the events to send a text message to the configured mobile phones and select the Send SMS check box. Continue to “Sending Event Messages by Mobile Phone” on page 55 to complete the configuration.
- **Send Page** – Select the events to send a page to the configured pagers and select the Send Page check box. Only these events can be configured: UPS Battery Low, UPS Hardware Failure, UPS Input Power Failure, and UPS Output Overload. Continue to “Sending Event Messages by Pager” on page 57 to complete the configuration.

Broadcasting a Message

 **NOTE:** Broadcasting is available only on the Microsoft Windows platform versions that include Messenger Service. Messenger Service is not included with Windows Vista, Windows 7, and Windows Server 2008. Users must have Messenger Service enabled on their computer to receive broadcast messages.

Select **Broadcast Setting** from the **Tools** menu or click the **Setting** button for Broadcast in the Event Action window. The Broadcast Message Settings window opens (see Figure 47).




Figure 47. Broadcast Message Settings Window

The **Broadcast To** area of the window lists the users who can be selected to receive broadcast messages, including all users, domain users, and specific users.

- **All Users** – Sends the message to all computers that are in the same network with the local Agent, whether or not the computer is in the same domain.
- **Domain User** – Sends the message only to all computers in the same domain with the local Agent.
- **Specific User** – Sends the message only to one or a group of defined users, but no others.

To add a new user:

- 1 Click **Add** to open the Add Broadcast User window (see Figure 48).




Figure 48. Add Broadcast User Window

- 2 Enter the username that will receive messages and click **OK**.

The names of the added users are shown in the **Broadcast To** area of the window.

To configure the broadcast settings (see Figure 49):

- 1 Select the user who will receive messages.
- 2 Select the events that will be sent to the user.
- 3 Click **OK**.

The settings are effective immediately.




Figure 49. Broadcast Message Settings

To remove a user, select the username and click **Remove**.

 **NOTE:** The All Users and Domain User items cannot be deleted.

Sending Event Messages by E-Mail

NOTE: To send e-mail messages when an event occurs, the computer with the Dell UPS Management Software installed must be connected to the Internet.

Select **E-mail Setting** from the **Tools** menu or click the **Setting** button for E-mail in the Event Action window. The E-Mail Settings window opens (see Figure 50).




Figure 50. E-Mail Settings Window

To configure the e-mail settings:

1 Enter the SMTP server settings:

Parameter	Description
SMTP Server	Enter the IP address (IPv4 address or IPv6 address) of the SMTP mail server that will be used to send e-mail to the selected users.
SMTP User	Enter the SMTP mail server login name with the complete address format. For example, <code>yyy@test.com.cn</code>
Password	If a password is required for the SMTP server, select the check box and enter the password for the account.

- 2 Enter the sender name and telephone number.
- 3 To send a daily e-mail at a specific time, select the check box and enter the time of day in 24-hour format (see Figure 51). The e-mail contains two attachments: the Event Log and Data Log files for the preceding 24 hours.




Figure 51. Sender Information

- 4 Select the Add button (see Figure 52). The Add Receiver E-mail Address window opens (see Figure 53).




Figure 52. Add Button




Figure 53. Add Receiver E-mail Address Window

- 5 Enter the receiver's e-mail address and click **OK** to save and exit.
- 6 Dell recommends testing the e-mail function by selecting the e-mail address and clicking the **Test** button. The software sends a test e-mail to the specified recipient.



NOTE: You can select the event messages from the E-Mail Settings window or from the Event Action window.

- 7 Verify that one or more recipient e-mail addresses are selected, and then select the event messages to be sent by selecting the message check box (see Figure 54).





Figure 54. E-Mail Recipient and Message Selection

If the selected event occurs, the software sends the e-mail to all of the selected addresses in the Receiver E-Mail list.

8 Click **OK** to save and exit.

To remove a recipient, select the e-mail address and click **Remove**.

Sending Event Messages by Mobile Phone

 **NOTE:** Sending local SMS text messages requires that the computer with the Dell UPS Management Software must have at least one communication port that is connected to a GSM modem or mobile phone.

Select **SMS Setting** from the **Tools** menu or click the **Setting** button for Send SMS in the **Event Action window**. The SMS Setting window opens (see Figure 55).




Figure 55. SMS Setting Window

To configure the SMS settings:

- 1 Select the communication port that is being used by a GSM modem or mobile phone (see Figure 56).
- 2 Set the baud rate for the communication port.
- 3 If you are located outside of Mainland China, select **Other** for Locus.




Figure 56. SMS Setting Window with Selections

- 4 In the Receiver list, enter up to five mobile telephone numbers to receive a text message. Enter only numbers with no spaces, alphanumeric characters, or symbols.
- 5 Dell recommends testing the SMS function by selecting a telephone number and clicking the **Test** button. The software sends a test text message to the specified recipient.




NOTE: You can select the event messages from the SMS Setting window or from the Event Action window.

- 6 Select the event messages to be sent by selecting the message check box. If the selected event occurs, the software sends the message to all of the telephone numbers in the Receiver list.
- 7 Click **OK** to save and exit.

To remove a recipient, select the telephone number and click **Remove**.

Sending Event Messages by Pager

 **NOTE:** Sending a page when an event occurs requires that the computer with the Dell UPS Management Software must have at least one communication port that is connected to a modem.

Select **Pager Setting** from the **Tools** menu or click the **Setting** button for Send Page in the Event Action window. The Pager Setting window opens (see Figure 57).




Figure 57. Pager Setting Window

1 Enter the applicable pager settings:

Parameter	Description
Modem Port	Select the communication port that is being used by the modem.
Access Number	Some pager services require a delay between dialing the access number and the message code. The Access Number is the station number that the pager joined (which can only be an auto station). The waiting time is the delay time between dialing the paging station number and the pager number; the delay time is set by the paging station. For example, the Liantong 192 auto station requires a one second delay.
Pager Number	Some pager services require a delay between dialing the pager number and the message code. The Pager Number is the number of the pager that accepts the communication. The wait time is the delay time between dialing the pager number and the message code (paging message content); the delay time is set by the paging station. For example, the Liantong 192 auto station requires a one second delay.
Dialing number to external line	For an external line, dial a specified number and delay a specified time to access the external line. If the external line phone number cannot be dialed directly, add the switch number in the Dialing to external line field. The wait time after dialing can be set as needed, generally one second.
Dialing number after message	Some pager services require a specific number to end the message code.

2 Dell recommends testing the pager function by clicking the **Test** button. The software sends a test page (000) to the specified recipient.



NOTE: You can select the event messages from the **Pager Setting** window or from the **Event Action** window.

3 Select the Event Code check boxes for the event messages to be sent (see Figure 58). Only these events can be configured: UPS Input Power Failure, UPS Battery Low, UPS Hardware Failure, and UPS Output Overload.

If the selected event occurs, the software sends the event code to the pager. The event code displays on the pager.

- 4 Click **OK** to save and exit.





Figure 58. Pager Setting Window

Resetting the Dell UPS Sensor Values

Select **UPS Control Parameters** from the **UPS** menu. The UPS Control Parameters window opens (see Figure 59).

 **NOTE:** If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. This setting must be enabled from the LCD before you can select UPS Control Parameters.




Figure 59. UPS Control Parameters Window


To reset the sensor values:

- 1 Select the check box for the options to reset:
 - Reset Peak Consumption Watts
 - Reset Cumulative Consumption Watts
 - Reset Peak Headroom Watts
- 2 Click **OK**.

The sensor values clear, and the date and time stamp for the statistic resets to the current date and time.

Setting up UPS Load Segment Control

The Load Segment Control window contains parameters to control each UPS load segment. Select **Load Segment Control** from the UPS menu to open the Load Segment Control window (see Figure 60).

 **NOTE:** If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. This setting must be enabled from the LCD before you can select Load Segment Control.




Figure 60. Load Segment Control Window

The parameters include:

- **Minimum battery charge level:** Shuts down the selected load segment when the battery capability is below its set percentage value.
- **Shutdown Timer:** Shuts down the selected load segment when the utility power fails for the amount of time equal to the setting time. The value range is -1 to 32,767 seconds.
- **Startup Timer:** Starts up the load segment when the set timer expires after utility power is restored. The value range is -1 to 32,767 seconds.
- **Manual Shutdown:** Shuts down the load segment immediately.
- **Manual Startup:** Starts the load segment immediately.

To configure the load segment:

- 1 Select the load segment to configure, or select the check box for Apply to All Load Segments.
- 2 Set the shutdown and startup parameters.
- 3 Click **OK** to save and exit.

Renaming the UPS Model

Select **UPS Alias Information** from the **UPS** menu to open the UPS Alias Information window (see Figure 61).






Figure 61. UPS Alias Information Window

 **NOTE:** If the Dell UPS Management Software automatically detects the UPS model, you cannot rename it.

Select the **UPS Model** from the drop-down menu. You can rename the UPS by selecting the **Rename UPS** check box and entering an alias for the UPS name.

Configuring Shutdown Parameters

Select **Shutdown Parameter** from the **UPS** menu or click the  icon from the toolbar to open the Shutdown Settings window (see Figure 62).





Figure 62. Shutdown Settings Window

 **NOTE:** The System checkbox is checked by default if software detects a UPS connected to the server through RS-232 or USB.



NOTE: If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. A read-only access message displays when you click OK (see Figure 63). You must enable this setting from the LCD before you can apply changes to the Shutdown Settings window.



Figure 63. UPS is Set to Read-Only Message



NOTE: If the Agent is connected to more than one UPS, each UPS has its own shutdown conditions.

The shutdown parameters are:

Parameter	Description
Allow battery to discharge for	The time that the UPS battery is able to supply power when utility power fails.
Shut down when remaining battery time is below	When the remaining battery time falls below the specified time, the output of the UPS turns off. The battery time range is 0 to 4320 minutes, 59 seconds. The default value is 2 minutes, 0 seconds.
Begin shutdown immediately if Battery Low	When a Battery Low event occurs, the Agent shuts down the UPS immediately; otherwise, the shutdown time is controlled by the battery backup time.
System Shutdown	The system shuts down while the selected UPS is being turned off.
System Suspend	The system is suspended to disk during the shutdown sequence. This function is available only on certain Microsoft Windows platforms, and Hibernate Support must be enabled from the Control Panel (Control Panel > Power Options > Hibernate).
Redundant UPS Input Setting	If there is a redundant UPS supplying power to the local Agent, you can safely shut down the local Agent before all UPSs shutdown. See “Redundant UPS Shutdown” on page 69 for more information.
Time needed for system shutdown	The time required to shut down the system, from the initiation of shutdown until it is complete.
Powered by	The Load Segment that powers the computer.
Remote Shutdown by Agent	Allows another Agent to shut down the selected UPS.
XX min shut down system	After receiving the specified Agent's shutdown signal, shutdown is delayed by XX minutes.

Parameter	Description
Run Command File before Shutdown	Before system shutdown, the Agent can initiate a command if this parameter is not zero. The Agent does not begin to shut down the system until the "Execute file before system shutting down" ends.
Shutdown File Max Execution Time	Before system shutdown, the time required to implement the shutdown file.
Shutdown Conditions	Displays the remote Agents to be shut down. You can add, modify, or remove the remote Agents.
Shutdown Alarm Interval	The number of minutes between each shutdown warning.
Start Warning before Scheduled Shutdown	The time in minutes before a scheduled shutdown when the Agent issues the first warning.

Remote Shutdown by Agent

To configure for shutdown by a remote Agent:

- 1** Select the Remote Shutdown by Agent check box and click **Add**.
- 2** Enter the IP address (IPv4 address or IPv6 address) or host name of the Agent.
- 3** Click **OK** to save and exit.

When the local Agent receives the specified Agent's shutdown signal, the system shuts down in the specified delay time.

Shutdown Remote Agents

To configure for shutting down remote Agents:

- 1 Click the **Add** button in the **Shutdown Conditions** area.

The Shutdown Remote Agents window opens (see Figure 64).




Figure 64. Shutdown Remote Agents Window

- 2 Select **Shutdown** or **On Battery**:

When the UPS of the Agent is going to shut down and Shutdown is selected, the software sends the shutdown command to the remote computers at the IP addresses that are listed in the Shutdown Remote Agents window.

When On Battery is selected, the software sends the shutdown command to the remote computers when the time of the UPS transfer to battery exceeds the specified time.

- 3 Select the Load Segment that powers the computer.
- 4 Enter the IP address (IPv4 address or IPv6 address) or host name and then click **Add** for each Agent to be shut down.
- 5 Click **OK** to save and exit.

When the shutdown condition is satisfied, the Agent sends a shutdown signal to the selected remote Agents.

You can view and set the shutdown condition of each UPS according to its actual status (see Figure 65).




Figure 65. Shutdown Conditions on the Shutdown Settings Window

Shutdown Devices Monitored by Network Management Card

To shut down devices monitored by the Network Management Card:

- 1 Select **SNMP** from the serial ports list (see Figure 66).

The UPS list displays the IP addresses for all of the devices monitored by the card.

- 2 Select one device to set the shutdown parameters.



NOTE: The SNMP shutdown function is available only in the local Agent shutdown setting.




Figure 66. SNMP List

Redundant UPS Shutdown

If there is a redundant UPS supplying power to the local Agent, you can safely shut down the local Agent before all UPSs shut down. Figure 67 shows a redundant UPS configuration.




Figure 67. Redundant UPS Configuration

Click the **Redundant UPS Input Setting** button to list all of the UPS devices (see Figure 68). Select the redundant UPS that has different shutdown conditions by selecting its check box. The system will not shut down until all the conditions of all selected UPSs are met.




Figure 68. Redundant UPS Input Group

Entering the UPS Warranty Period

Select **UPS Warranty Period Setting** from the **UPS** menu to open the **UPS Purchase Date Setting** window (see Figure 69).




Figure 69. UPS Purchase Date Setting Window

Enter the **UPS Purchase Date**, **Battery Purchase Date**, **UPS Warranty Period**, and the **Battery Warranty Period**.

You can also remind users of upcoming warranty expiration dates or that the warranty period has expired.

To remind the user every month that the warranty has expired:

- 1 Select the **Remind user that warranty period expired on** check box (see Figure 70).




Figure 70. Monthly Warranty Expiration Warning Settings Example

- 2 Type or select the day of the month in the **Days** box.
- 3 Type or select the time of day in the **every month** box.
- 4 Select the **Enable Warranty Period warning** check box.

The message displays at the top of the of the UPS status diagram and a reoccurring monthly warning message displays on the selected day and time (see Figure 71).




Figure 71. Warranty Expiration Warning Message

NOTE: For a one-time warranty expiration message, do not select the Remind user that warranty period expired on box (see Figure 72).




Figure 72. One-Time Warranty Expiration Warning Settings Example

Testing the UPS

You can perform a UPS self-test immediately or schedule a UPS self-test.

Performing a UPS Self-Test Immediately

Select **Request Battery Test** from the **UPS** menu to open the Request Battery Test window (see Figure 73).


 **NOTE:** If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. This setting must be enabled from the LCD before you can select Request Battery Test.



Figure 73. UPS Self-Test Immediately Window

Select the **Self-Test** option and click **OK** to start the UPS self-test.

Click **Cancel Current UPS Self-Test** from the **UPS** menu to cancel the self-test process immediately.

Scheduling a UPS Self-Test

Select **Battery Self-Test Schedule** from the **UPS** menu to open the **UPS Test Manager** window (see Figure 74). You can schedule a UPS self-test for one time only or on a monthly basis.




Figure 74. UPS Test Manager Window

The UPS Test Manager window displays a calendar at the top and the task list at the bottom. All of the UPS self-test and UPS on/off tasks are shown in the task list. The calendar displays a red dot for the UPS power off action, a green dot for the UPS power on action, and a blue dot for the UPS self-test action.

To schedule a UPS self-test:

- 1 Click **Add Test** to open the UPS Self-Test window (see Figure 75).





Figure 75. UPS Self-Test Window

- 2 Select how often to perform the UPS self-test: **Once** or **Monthly**.
- 3 Select the start date and time for the UPS self-test.

 **NOTE:** The scheduled date and time cannot conflict with another scheduled UPS task.

- 4 Select the **Self-Test** option.
- 5 Select the UPS to test.

6 Click **OK** to save and exit.


 **NOTE:** If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. A read-only access message displays when you click **OK**. (see Figure 76). You must enable this setting from the LCD before you can apply changes to the UPS Self-Test window.



Figure 76. UPS is Set to Read-Only Message

The UPS Test Manager window displays the task with a blue dot on the scheduled day and lists the detailed information in the task list (see Figure 77).




Figure 77. UPS Test Manager Window

Changing a Scheduled UPS Self-Test

To modify a scheduled UPS self-test:

- 1 Select one of the UPS self-test tasks in the task list.
- 2 Click **Modify** and then update the schedule (see Figure 78).
- 3 Click **OK** to save and exit.




Figure 78. Modify Task

Removing a Scheduled UPS Self-Test

To remove a scheduled UPS self-test:

- 1 Select a UPS self-test from the task list.
- 2 Click **Remove** to cancel the task (see Figure 79).




Figure 79. Remove Task

Turning the UPS On/Off

You can remotely turn the UPS off and on using the Dell UPS Management Software.

Scheduling a UPS On/Off Task

Select **UPS On/Off Schedule** from the **UPS** menu to open the UPS On/Off Manager window (see Figure 80). You can schedule a UPS On/Off task for one time only or on a weekly basis.




Figure 80. UPS On/Off Manager Window

The UPS On/Off Manager window displays a calendar at the top and the task list at the bottom. All of the UPS self-test and UPS on/off tasks are shown in the task list. The calendar displays a red dot for the UPS power off action, a green dot for the UPS power on action, and a blue dot for the UPS self-test action.

To schedule a UPS On/Off task:

- 1 Click **Add UPS On/Off** to open the UPS On/Off window (see Figure 81).





Figure 81. UPS On/Off Window

- 2 Select how often to perform the UPS On/Off task: **Once** or **Weekly**.
- 3 Select the start dates and times for the UPS On/Off tasks.

 **NOTE:** The scheduled date and time cannot conflict with another scheduled UPS task.

The UPS Power Off time range (from shutdown to next startup) is 1 to 9999 minutes (the maximum time is 6 days, 22 hours, and 39 minutes). The range for the year is 2009–2035.

- 4 Select the UPS to turn off and on.

5 Click **OK** to save and exit.


 **NOTE:** If the UPS Control Commands from Serial Port setting is disabled, configuration and load control commands are restricted to the LCD only. A read-only access message displays when you click **OK**. (see Figure 82). You must enable this setting from the LCD before you can apply changes to the UPS On/Off window.



Figure 82. UPS is Set to Read-Only Message

The UPS On/Off Manager window displays the task with a red or green dot on the scheduled day and lists the detailed information in the task list (see Figure 83).




Figure 83. UPS On/Off Manager Window

Changing a Scheduled UPS On/Off Task

To modify a scheduled UPS On/Off task:

- 1 Select one of the UPS On/Off tasks in the task list.
- 2 Click **Modify** and update the schedule (see Figure 84).
- 3 Click **OK** to save and exit.




Figure 84. Modify a Scheduled UPS On/Off Task

Removing a UPS On/Off Task

To remove a scheduled UPS On/Off task:

- 1 Select a UPS On/Off task from the task list.
- 2 Click **Remove** to cancel the task (see Figure 85).





Figure 85. Remove Scheduled UPS On/Off Task

Viewing Scheduled Tasks

Select View Schedule from the UPS menu or click the  icon from the toolbar to open the View Schedule window (see Figure 86). The View Schedule window displays only the tasks for the current month. Select another month to display the tasks for that month.






Figure 86. View Schedule Window

Remotely Controlling a UPS on the LAN or Internet

You can remotely monitor any Dell UPS within the same LAN or on the Internet. Up to 32 remote Agents can be monitored.


 **NOTE:** To remotely monitor any Dell UPS within the same LAN, the computers involved must have TCP/IP communication protocol.

 **NOTE:** To remotely monitor any Dell UPS on the Internet, the computers involved must have TCP/IP communication protocol and must be connected to the Internet.

To remotely control a UPS:

- 1 Test the performance of the physical network communication:

From a command prompt, enter the **ping** command with the IP address of the computer to be monitored. Figure 87 shows that the physical link is in an optimal state.



```
C:\WINNT\system32\cmd.exe

C: \>ping 192.168.1.228

Pinging 192.168.1.228 with 32 bytes of data:

Reply from 192.168.1.228: bytes=32 time<10ms TTL=128
Reply from 192.168.1.228: bytes=32 time<10ms TTL=128
Reply from 192.168.1.228: bytes=32 time<10ms TTL=128
Reply from 192.168.1.228: bytes=32 time<10ms TTL=128

Ping statistics for 192.168.1.228:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C: \>
```

Figure 87. Pinging the Computer to be Monitored

- 2 Enable the Accept Remote Control option in the Dell UPS Management Software:
Select **Accept Remote Control** from the **Monitor** menu (see Figure 88).




Figure 88. Accept Remote Control

The Dell UPS Management Software window opens (see Figure 89).




Figure 89. Dell UPS Management Software Window

3 Select a UPS to monitor:

Select the UPS from the tree view on the left side of the window or select Monitor Remote UPS from the Monitor menu.

If you selected the UPS from the tree view, continue to Step 5.

If you selected Monitor Remote UPS, continue to Step 4.

4 The Monitor Remote UPS window opens (see Figure 90).

Enter an IP address (either IPv4 or IPv6 address) or host name of the Agent and then click **OK**.




Figure 90. Monitor Remote UPS Window

5 The UPS name displays in the tree view directory (in the LAN directory for LAN connections or in the WAN directory for Internet connections).

If the Accept Remote Control option of the Agent is off, you can only remotely monitor the UPS. All control functions are disabled (see Figure 91).




Figure 91. Control Functions Disabled

If the Accept Remote Control option of the Agent is on, you can remotely monitor and control the UPS. All control functions are available (see Figure 92).




Figure 92. Control Functions Enabled

You can manually delete a remote Agent by right-clicking the selected Agent and clicking **Delete** (see Figure 93).




Figure 93. Delete Remote Agent

Monitoring a UPS through SNMP

You can use SNMP to monitor UPSs that have a Network Management Card installed. Up to 1,000 SNMP nodes can be monitored.

To add an area to the SNMP node:

- 1 Select the SNMP node from the tree view on the left side of the window.
- 2 Click **Add Area** from the SNMP menu.
- 3 Enter the geographic address of the SNMP card and click **OK** (see Figure 94).




Figure 94. Add Area Window

The new area displays under the SNMP node in the tree view (see Figure 95).






Figure 95. New SNMP Area

To add devices:

- 1 Click **Search Device** from the **SNMP** menu.
 - 2 Select the Internet Protocol Version supported by SNMP from the **Protocol Type** list (see Figure 96).
-  **NOTE:** The Protocol Type list displays only if both IPv4 and IPv6 are enabled.
-  **NOTE:** For IPv4, both single device and segment devices searches are supported.
- 3 **IPv4 only.** Enter an IPv4 address in the Start IP field and the End IP field (see Figure 96).





Figure 96. Search Device Window (IPv4)

4 IPv6 only. Enter the device's IP address (see Figure 97).

 **NOTE:** If the IPv6 address is a broadcast IP, all Network Management Cards that support IPv6 within the LAN are found. The default IPv6 address is broadcast IP ff02::1.




Figure 97. Search Device Window (IPv6)

- 5 Click Search.

After searching, the new device displays in the tree view (see Figure 98).




Figure 98. New Device in SNMP Area

NOTE: If one or more SNMP IP addresses in the search range are disabled, a pop-up window opens displaying the disabled IP addresses (see Figure 99). Select the IP address to go to the Network Management Card's Web page and configure the SNMP IP settings to enable the IP address.




Figure 99. Disabled IP Address Window

- Double-click the new device node to connect it with the Internet browser of the Network Management Card (see Figure 100). The Link column indicates successful communication.




Figure 100. Successful Link

- 7 To view the event records for any Dell UPS monitored by a Network Management Card, select the UPS under the SNMP node in the tree view and select **SNMP Event Log** from the **SNMP** menu. The Event Log for the selected UPS opens (see Figure 101).




Figure 101. Event Log

- 8 To set the maximum Event Log file length for any Dell UPS monitored by the Network Management Card, select **Event Log Setting** from the **SNMP** menu. The default file length is 5,000 rows, and the maximum value is 100,000 rows (see Figure 102).




Figure 102. Event Log Setting Window

Rebooting Computers after a Utility Failure

You can reboot individual computers or all computers on the LAN automatically after a utility power failure.

To configure the computers to reboot when the utility power restores:

- 1 Select **Wake Up** from the **UPS** menu to open the Wake on LAN window (see Figure 103).





Figure 103. Wake on LAN Window

- 2 To reboot all computers, select the Select all check box and click **OK**.
- 3 To reboot individual computers:
 - Enter the MAC address for the computer. You can use the `ipconfig -all` command to identify the MAC address of the computer.
 -  **NOTE:** DO NOT enter the dash (-) of the MAC address.
 - Click **Add**.
 - Repeat for each computer that should be rebooted when the utility power restores.
- 4 Dell recommends to test the reboot function.

To test the reboot function, select the computers from the list and click **Test**. The computers should reboot.

Exporting Configuration Parameters

Instead of configuring the software settings individually on multiple computers, you can easily copy the software configuration parameters to another computer.

To copy the configuration parameters to another computer:

- 1 From the configured Agent, select **Export Configuration** from the **System** menu (see Figure 104).




Figure 104. Export Configuration

The software exports a file that contains the saved configuration parameters, such as local UPS information, Network Management Card settings, shutdown parameters, and alarm settings.

- 2 Save the *.ini file.

- 3 From the new Agent, select **Import Configuration** from the **System** menu (see Figure 105).
- 4 Select the *.ini file and click **OK**.

Once the configuration parameters are imported, the settings take effect immediately.




Figure 105. Import Configuration

Event Descriptions

This chapter lists events logged by the Dell UPS Management Software (see “Viewing the Event Log” on page 41). Events can be set up to send an event message through broadcasting, e-mail, and text messaging. Some events can also be sent as a page to configured pagers, or set up to open a message window on your computer. See “Configuring Event Actions” on page 44.

Number	Event Description	Type of Message	Remarks
1	UPS Battery Low	Serious	In the Shutdown Settings, select UPS Battery Low so that when this event occurs, the UPS shuts down according to the shutdown parameters.
2	UPS Output Overload	Serious	Output load is more than 110%.
3	Communication Lost	Warning	The communication cable is not connected, or there is a communication port fault.
4	AC Fail	Warning	
5	On Bypass	Warning	The UPS transfers to Bypass mode because of overload, hardware fault, or other conditions. An online UPS is also in Bypass mode when it is off, at which time the UPS provides no protection.
6	Battery Test Fail	Warning	
7	AC Restore	Information	
8	Communication Established	Information	
9	Agent Start	Information	
10	Agent Stop	Information	
11	System to be Shut Down	Information	
12	System to be Shut Down by Another Agent	Information	Set the Agent to respond to through Shutdown Settings.
13	Specific Date UPS Shutdown	Information	
14	Weekly UPS Shutdown	Information	
15	Self-Test Started	Information	Self-test begins immediately.
16	Self-Test Canceled	Information	

Number	Event Description	Type of Message	Remarks
17	Self-Test Ended	Information	
18	Specific Date Self-Test Started	Information	
19	Specific Date Self-Test Canceled	Information	
20	Specific Date Self-Test Ended	Information	
21	Monthly Self-Test Started	Information	
22	Monthly Self-Test Canceled	Information	
23	Monthly Self-Test Ended	Information	
24	UPS Control Power ON	none	
25	On Manual Bypass	Alarm only	Applies to 5600W and double-conversion UPS models only.
26	In High Efficiency Mode	none	Applies to double-conversion UPS models only.
27	ON Buck / Input Voltage Reducer	none	
28	ON Boost / Input Voltage Booster	none	
29	ABM State Charging	none	
30	ABM State Floating	none	
31	ABM State Resting	none	
32	ABM State OFF	none	
33	Clock Set Done	none	
34	To Bypass Command	none	Applies to 5600W and double-conversion UPS models only.
35	From Bypass Command	none	Applies to 5600W and double-conversion UPS models only.
36	UPS On Command	none	
37	UPS Off Command	none	
38	Battery Disconnected	Alarm only	
39	Shutdown Imminent	Alarm only	

Number	Event Description	Type of Message	Remarks
40	Service Battery	Alarm and disables battery charging (ABM in Charger Off mode)	
41	Utility Not Present	Alarm and transfers to battery if supporting the load; otherwise, powers down	Utility level has fallen below the Utility Not Present threshold (typically < 25 to 50V).
42	Bypass Not Available	Alarm and inhibits bypass transfer	Applies to 5600W and double-conversion UPS models only.
43	Input AC Overvoltage	Alarm and transfers to battery if supporting the load; otherwise, turns off converters	
44	Input AC Undervoltage	Alarm and transfers to battery if supporting the load or powers down if not	
45	Input Under/Over Frequency	Alarm and transfers to battery if supporting the load	
46	Site Wiring Problem	Alarm only	
47	Remote Emergency Power Off	Alarm and de-energizes load and enters standby mode	
48	Overload L2	Alarm and then transfers to bypass in 2 minutes	
49	Overload L3	Alarm and then transfers to bypass in 30 seconds	
50	Battery DC Overvoltage	Alarm only	
51	Charger Failure	Alarm only	
52	Inverter AC Overvoltage	Alarm and then transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.
53	Inverter AC Undervoltage	Alarm and transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.
54	Rectifier Input Overcurrent	Alarm and transfers to battery if supporting the load or if converters are off	Applies to double-conversion UPS models only.
55	Inverter Output Overcurrent	Alarm and transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.

Number	Event Description	Type of Message	Remarks
56	DC Link Overvoltage	Alarm and transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.
57	DC Link Undervoltage	Alarm and transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.
58	Inverter Fault	Alarm and inhibits recovery attempts	Applies to double-conversion UPS models only.
59	Rectifier Fault	Alarm and inhibit recovery attempts	Applies to double-conversion UPS models only.
60	Output Short Circuit	Alarm	
61	Heatsink Overtemperature	Alarm and transfer to bypass if supporting the load or if converters are off	
62	Fatal EEPROM Fault	Alarm only	
63	Fan Failure	Alarm only	
64	DC Link Imbalance	Alarm and transfers to bypass if supporting the load or if converters are off	Applies to double-conversion UPS models only.
65	Bypass Over/Under Frequency	Alarm only	
66	Warranty Period Has Expired	Information	
67	Warranty Period Is Less Than One Year	Information	
68	Output Off	Alarm only	
69	Output Normal	Information	

Installation on a VMware ESX Server

This guide describes the installation and configuration of the Dell UPS Management Software on a VMware® ESX® Server.

Dell UPS Management Software allows you to connect a 3.x or 4.x VMware ESX Server with a UPS through the UPS RS-232 port, USB port, or through the Network Management Card. The software will be monitored and configured by a remote Agent on either a Microsoft Windows or Linux platform (see Figure 106).

The software notifies the VMware server of power events or UPS alerts with pop-up broadcast information on the console. It also safely shuts down the VMware ESX server and the guest operating system.

Before the VMware ESX system shuts down, use the **shutdown.sh** script to shut down the guest operating system.

All operations are tested on VMware server with two guest operating systems (SBS 2003 and Red Hat) when the certain conditions exist, such as:

- UPS Battery is low
- Battery backup time is reached
- Battery discharge time is reached

Tested operations include:

- Safely shuts down the VMware server
- Safely shuts down the guest operating system
- Software notifies the VMware server of power events or the UPS alerts

Figure 106 shows an overview of the VMware environment.




Figure 106. VMware ESX Environment Structure Overview

Installation

This guide provides information about installing and configuring Dell UPS Management Software on a VMware ESX server and installing VMware Tools on a guest operating system.

Prerequisites

- VMware ESX Server with 125 MB free space for the software.
- VMware Infrastructure client must be installed on different machine.

Dell UPS Management Software Installation

To install the software:

- 1 Download the software from the Dell Web site (support.dell.com) or from the CD (F618R A04 or higher) provided with the UPS.
- 2 To install the software from the CD, enter the following command:

```
mount /dev/cdrom /mnt  
cd /mnt/Linux  
./setup_console.bin
```

- 3 To install the software file downloaded from the Dell Web site:
 - Go to the location where the software was downloaded.
 - Enter `tar -zxvf UPSMS_setup_Linux.tar.gz` to extract the file.
 - Enter `./setup_console.bin` to install the software.
- 4 Enter the installation path: `/opt/ups`
- 5 To start the Agent, enter the command:

```
./agent start
```

Installing VMware Tools on a Microsoft Windows Guest

To install the VMware Tools for a Microsoft Windows guest:

- 1 On the VM Templates page, select the virtual machine template name and then select the **Console** tab. The virtual machine console displays (see Figure 107).




Figure 107. Console Window

- 2 Insert and start the Microsoft Windows operating system installation CD.

- 3 Log in to the guest operating system from the virtual machine console.
- 4 Select the template name and then right-click and select **Install/Upgrade VMware Tools** from the menu (see Figure 108).




Figure 108. Virtual Machine Template Menu

- 5 From within the guest operating system, click **OK** to confirm that you want to install VMware Tools and launch the Install Shield wizard.
 - If auto-run is enabled in the guest operating system (the default setting for Microsoft Windows operating systems), a window opens.
 - If auto-run is not enabled, run the VMware Tools installer. Click **Start > Run** and enter **D:\setup.exe**, where D: is the first virtual CD-ROM drive.
- 6 Follow the on-screen instructions.
 - On Microsoft Windows Server 2003, the SVGA driver is installed automatically, and the guest operating system uses it after it reboots.
 - After you install VMware Tools, Microsoft Windows 2000 and Microsoft Windows XP guest operating systems must be rebooted to use the new driver.

Installing VMware Tools on a Linux Guest

The VMware Tools installation package is on the VMware server installation CD on the path \VMware\RPMS.

- 1 On the VM Templates page, select the virtual machine template name and then select the **Console** tab. The virtual machine console displays (see Figure 109).




Figure 109. Console Window

- 2 Insert and start the VMware server installation CD.
- 3 Log in to the guest operating system from the virtual machine console (see Figure 110).




Figure 110. Console Window – Log In

- 4 Select the template name and then right-click and select **Install/Upgrade VMware Tools** from the menu (see Figure 108).
- 5 Mount the CD with the command:

```
mount /dev/cdrom /mnt
```

- 6 Install the package with the command:

```
cd /mnt/VMware/RPMS
rpm -Uvh VMware-esx-tools-3.5.0-123630.i386.rpm
```



NOTE: The package name is likely to be different.

7 Configure the VMware Tools with the command:

```
vmware-config-tools.pl
```

8 Enter number: 1

9 Start the VMware Tools with the command:

```
vmware-toolbox &
```

VMware Tools on the summary row displays **OK** if the tools are available (see Figure 111).




Figure 111. VMware Tools Available

Configuration

This section explains configuration for the Dell UPS Management Software and for the VMware server.

VMware Server Configuration

All hardware elements must have an operational network configuration that allows them to communicate freely with each other. Dell UPS Management Software uses TCP and UDP for communication with UPS.

To configure the VMware Server:

- 1 Confirm that the following UDP ports are opened on the ESX server Firewall. Check the ports according to the following table:

Communication Mode	Ports
USB/RS-232	2198, 2199, 2200
Network Management Card	161, 162, 3369

Example command:

```
esxcfg-firewall -o 2198,udp,in,UPSMS
```

- 2 Confirm that the following TCP ports are opened on the ESX server Firewall: 2099

Example command:

```
esxcfg-firewall -o 2099,tcp,in,UPSMS
```


- 3 If you want to disable the firewall permanently, enter the command:

```
chkconfig iptables stop
```

- 4 To disable the firewall temporarily, enter the command:

```
service iptables stop
```


Communication Through an RS-232 or USB Port

 **NOTE:** USB communication is only available for VMware ESX 4.0.

The VMware server works in console mode and cannot be used for configuration. Use a remote Agent with the same Dell UPS Management Software version to configure the VMware server.

- 1 Start the manager interface on the remote software Agent in the Microsoft Windows operating system.
- 2 If the two Agents are in the same LAN, the VMware server client will be added to the topology automatically; otherwise, add the Agent manually (select **Monitor Remote Device** from the **Monitor** menu).

The software automatically searches for the UPS when the Agent starts for the first time after installation.

If the search fails:

- Select the **VMware Server Agent** from the tree view.
- Acting as the Administrator, select **Auto Search Device** from the **System** menu. The UPS connected with VMware Server appears in the LAN tree view (see Figure 112).




Figure 112. UPS Connected to the VMware Server

- 3 Select **Shutdown Parameter** from the UPS menu.
- 4 On the Shutdown Settings page (see Figure 113):
 - Set the battery backup time
 - Select the **Begin Shutdown Immediately if Battery Low** check box
 - Select the **Run Command File before Shutdown** check box
 - Set the **Shutdown File Max Execution Time**. Allow at least 30 seconds for each guest operating system shutdown.





Figure 113. Shutdown Options

Communicating Through the Network Management Card

 **NOTE:** See Table 4 on page 133 for a complete list of Dell Command User Interface (CUI) commands.

The following procedure is an example of a user entering the settings for a graceful shutdown of selected devices through the network management card:

- 1 Enter the installation path: `/opt/ups`
- 2 Enter `./CuiManager` to start the CuiManager (see Figure 114).
- 3 Search for a single device by entering `search4` and the device network IP address, or search for multiple devices within a range.

Example command:

```
search4 -ip 172.18.127.1 -ip 172.18.127.254 -c public
```

All devices in the network IP address from 172.18.127.1 to 172.18.127.254 are added.

```
Dell_UPS_Management_Software_InstallLog.log  RMI.lax      UPSPILLOT.TRA
etc                                           S99UPS      UPSPILLOT.TSF
Exit                                          serial      upsstart
Exit.lax                                     shutdownesxi.sh  UPSTIME.LOG
ghettoShutdown.pl                          shutdownESXi.sh upsUIShutdown.pl
help                                         shutdownOS   VMwareESXHosts

[ovi-admin@liuqiong ups]$ sudo ./agent start
Starting Agent:
Done
[ovi-admin@liuqiong ups]$ ./CuiManager
CuiManager is starting...
Dell UPS Management Software - only for SNMP Device, version: 01.05.0004 2009-01
-22
Any command using option "-help" will show it's messages!!
Dell Manager>search4 -ip 172.18.127.1 -ip 172.18.127.254 -c public
Searching SNMP from 172.18.127.1 to 172.18.127.254
Start Searching Thread...
Dell Manager>Search is Completed, Found 3 UPS, Added 3 UPS
Dell Manager>list
ip          statu      model
--          -
172.18.127.75      C1K
172.18.127.24      Powerware BladeUPS
172.18.127.47      Dell UPS Rack 4200W High Efficiency Online HU - 230U
Dell Manager>_
```

Figure 114. Searching for Devices

- 4 Enter the shutdown commands (see Figure 115).

Example:

```
shutsys -ip 172.18.127.47 -e true
```

```
shutbackup -ip 172.18.127.47 -e true -m 1:00
```

```
shutfile -e true -f shutdown.sh -m 2
```

```
listshut -ip 172.18.127.47
```



NOTE: See “Dell CUI Commands” on page 133 for a description of all Dell CUI commands.



NOTE: Each guest operating system requires a minimum of 30 seconds to run the command file before shutdown. The -m 1 option in the shutfile command in the example below sets one minute as the total time allowed to run the command file before shutdown, which allows sufficient time for two guest operating systems.

Example: `shutfile -e true -f shutdown.sh -m 1`

The host and guest operating system shut down orderly and gracefully after the battery discharges for one minute.

```
etc
Exit
Exit.lax
ghettoShutdown.pl
help
[vi-admin@liuqiong ups]$ ./CuiManager
CuiManager is starting...
Dell UPS Management Software - only for SNMP Device, version: 01.05.0004 2009-01
-22
Any command using option "-help" will show it's messages!!
Dell Manager>shutsys -ip 172.18.127.47 -e true
Dell Manager>shutbackup -ip 172.18.127.47 -e true -m 1:00
Dell Manager>shutfile -e true -f shutdown.sh -m 2
Dell Manager>listshut -ip 172.18.127.47
172.18.127.47 Dell UPS Rack 4200W High Efficiency Online HV - 230V
Allow battery to discharge for Enable 01:00
Shut down when remaining battery time is below Disable 02:00
Begin Shutdown Immediately if Battery Low Disable
System Enable
Powered by Load Segment1
Run Command File before Shutdown Enable /opt/ups/shutdow

Shutdown File Max Execution Time 2 min

Dell Manager>_
```

Figure 115. Shutdown Parameters

Installation on a VMware ESXi Server

This guide describes the installation and configuration of the Dell UPS Management Software on a VMware® ESXi® Server.

The Dell UPS Management Software agent cannot be installed on the hypervisor system because VMware® ESXi does not have an administrative console for hypervisor. However, the software can be installed on VMware Infrastructure Management Assistant (VIMA) 1.0 or on vSphere Management Assistant (vMA) 4.0 to manage the shutdown of VMware ESXi hosts. You can configure the ESXi to safely and orderly suspend or shutdown guest operating systems by configuring the ESXi hypervisor. This allows one Dell Software agent on one guest operating system (VIMA/vMA).

Dell UPS Management Software allows you to connect a 3.x or 4.x VMware ESXi with a UPS through the Network Management Card.

The software notifies the VMware server of power events or UPS alerts with pop-up broadcast information on the console. It also safely shuts down the VMware ESXi server and the guest operating system.

Before the VMware ESX system shuts down, use the **shutdownESXi.sh** script to shut down the guest operating system.

All operations are tested on VMware server with two guest operating systems (SBS 2003 and Red Hat) when certain conditions exist, such as:

- UPS battery is low
- Battery backup time is reached
- Battery discharge time is reached

Tested operations include:

- Safe shut down of the VMware server
- Safe shut down of the guest operating system
- Notifications of any power events or UPS alerts to the VMware server




Figure 116. VMware ESXi Environment Structure Overview

Installation and Configuration

This guide provides information about installing and configuring the Dell UPS Management Software on a VMware ESXi server and installing VMware Tools and vMA 4.0 on a guest operating system.

Prerequisites

- VMware ESXi server machine
- VIMA 1.0 or vMA 4.0 installed as guest
- VMware Infrastructure client installed on a different machine for VMware ESXi Server configuration
- Secure Copy Protocol (SCP) client like WinSCP to upload packages to the VMware ESXi server
- Dell UPS Management Software installed on the vMA


vMA Installation

To install the vMA application:

- 1** Go to <http://www.vmware.com/support/developer/vima/> to download the software from the VMware Web site.
- 2** Unzip the vMA virtual application package.
- 3** Start the VMware Infrastructure client:
 - Select **File > Deploy OVF Template**.
 - Click **Browse**.
 - Select the Open Virtualization Format (OVF) and click **Next**.

vMA Configuration

To configure the vMA software:

 **NOTE:** The default user name is **vi-admin**.

- 1 Enter the following command to add Target Servers to vMA:

```
sudo vifp addserver <servername>
```

Example command: `sudo vifp addserver 172.18.127.11`

- 2 Enter the following command to enable seamless authentication for remote CLI and VI Perl Toolkit:

Example command: `sudo vifpinit 172.18.127.11`

- 3 Verify that the target server has been added. Enter the following command to display target servers:

```
sudo vifp listservers
```

Example response: `172.18.127.11 ESXi`

VMware ESXi Server Configuration

To allow interactions between physical and virtual machines, VMware tools must be installed on each virtual machine. Go to http://www.vmware.com/pdf/osp_install_guide.pdf to download the *VMware Tools Installation Guide Operating System Specific Packages* on the VMware Web site for further information.

Installing VMware Tools on a Microsoft Windows Guest Operating System

To install the VMware Tools for a Microsoft Windows guest operating system:

- 1 On the VM Templates page, select the virtual machine template name and then select the **Console** tab. The Console window opens (see Figure 117).




Figure 117. Console Window

- 2 Insert and start the Microsoft Windows operating system installation CD.

- 3 Log in to the guest operating system from the virtual machine console.
- 4 Select the template name and then right-click and select **Guest>Install/Upgrade VMware Tools** from the menu. (see Figure 118.)




Figure 118. Virtual Machine Template Menu

- 5 From within the guest operating system, click **OK** to confirm that you want to install VMware Tools and launch the Install Shield wizard.
 - If auto-run is enabled in the guest operating system (the default setting for Microsoft Windows operating systems), a window opens.
 - If auto-run is not enabled, run the VMware Tools installer. Click **Start > Run** and enter **D:\setup.exe**, where D: is the first virtual CD-ROM drive.
- 6 Follow the on-screen instructions.
 - On Microsoft Windows Server 2003, the SVGA driver is installed automatically, and the guest operating system uses it after it reboots.
 - After you install VMware Tools, Microsoft Windows 2000 and Microsoft Windows XP guest operating systems must be rebooted to use the new driver.

Installing VMware Tools on a Linux Guest Operating System

To install the VMware Tools for a Linux guest operating system:

- 1 On the VM Templates page, select the virtual machine template name and then select the **Console** tab. The Console window opens (see Figure 119).




Figure 119. Console Window

- 2 Insert the VMware server installation CD.
Go to `\VMware\RPMS` to locate the VMware Tools installation package.
- 3 Log in to the guest operating system from the virtual machine console (see Figure 120).





Figure 120. Console Window – Log In

- 4 Select the template name and then right-click and select **Install/Upgrade VMware Tools** from the menu. (see Figure 118.)
- 5 Mount the CD with the command:


```
mount /dev/cdrom /mnt
```
- 6 Install the package with the command:


```
cd /mnt/VMware/RPMS
rpm -Uvh VMware-esx*.rpm
```

 **NOTE:** The package name is likely to be different.
- 7 Configure the VMware Tools with the command:


```
vmware-config-tools.pl
```
- 8 Enter number: 1

9 Start the VMware Tools with the command:

`vmware-toolbox &`

VMware Tools on the summary page displays **OK** if the tools are available (see Figure 121).




Figure 121. VMware Tools Available

VIMA/vMA Shutdown and Startup Configuration



NOTE: You can configure the physical machine to boot the automatic operating system on startup. This setting is located in your machine's basic input/output system (BIOS). For further information, refer to your specific technical hardware documentation.



NOTE: You can configure the automatic startup and shutdown properties of guest operating systems as suspended.

- Automatic Shutdown of guest (VIMA/vMA) when ESXi host is shutting down and
- Automatic Startup of guest (VIMA/vMA) when ESXi host is starting

To configure VIMA/vMA shutdowns and startups:

- 1 Choose the host server from the left pane tree hierarchy by the Virtual Infrastructure Client interface and then select the Configuration tab.
- 2 Select **Virtual Machine Startup/Shutdown** from the Software list and click **Properties**. The Virtual Machine Startup and Shutdown window opens (see Figure 122).

3 Enter the settings as shown on the Virtual Machine Startup and Shutdown window:

- For each virtual machine, set delay startup for 10 seconds
- For each virtual machine, set delay shutdown for 30 seconds




Figure 122. Startup/Shutdown Settings



NOTE: All hardware elements must have an operational network configuration that allows them to communicate freely with each other. The Dell UPS Management Software uses TCP and UDP for communication with UPS.

- 4 Confirm that the following UDP ports are enabled on the VIMA/vMA firewall: 161, 162, and 3369

Example commands:

```
sudo iptables -I INPUT -p udp --dport 161 -j ACCEPT
```

```
sudo iptables -I OUTPUT -p udp --dport 161 -j ACCEPT
```

- 5 Confirm that the following TCP port is enabled on the VIMA/vMA firewall: 2099

Dell UPS Management Software Installation

To install the software:

- 1 Start the vMA 4.0 guest operating system.
- 2 Download the software from the Dell Web site (support.dell.com) or from the CD (F618R A04 or higher) provided with the UPS.
- 3 Upload the software from Windows to vMA 4.0 using WinSCP tools.
- 4 Copy the **Linux** and **InstallerData** files from the CD to vMA.
- 5 Enter the following commands to access the **Linux** and **InstallerData** files:

```
sudo chmod -R 777 Linux
```

```
sudo chmod -R 777 InstallerData
```

- 6 Enter the **Linux** path and then enter the following command to install the software:

```
cd Linux
```

```
sudo ./setup_console.bin
```

- 7 Edit the document “VMwareESXHosts” on the installation path.

Add all ESXi server host IP addresses, separated by spaces. Add the IP address of the ESXi server on which VIMA/vMA is installed as the last entry.

Example: 172.18.127.13 172.18.127.12 172.18.127.11




NOTE: To configure each server, see “vMA Configuration” on page 120.

- 8 Start the Agent. From the installation path, enter the command:

```
sudo ./agent start
```

Shutdown Parameter Setting for Network Management Card

The following procedure is an example of entering the settings through the network management card for a graceful shutdown of selected devices.


 **NOTE:** See Table 4 on page 133 for a complete list of Dell Command User Interface (CUI) commands.

- 1 Go to the installation path.
- 2 Enter `./CuiManager` to start the CuiManager (see Figure 123).
- 3 Search for a single device by entering `search4` and the device network IP address, or search for multiple devices within a range.

For example:

```
search4 -ip 172.18.127.1 -ip 172.18.127.254 -c public
```

All devices in the network IP address from 172.18.127.1 to 172.18.127.254 are added.



```
Dell_UPS_Management_Software_InstallLog.log  RMI.lax      UPSPILLOT.TRA
etc                                           S990UPS     UPSPILLOT.TSF
Exit                                          serial      upsstart
Exit.lax                                     shutdownesxi.sh  UPSTIME.LOG
ghettoShutdown.pl                          shutdownESXi.sh  upsUIShutdown.pl
help                                         shutdownOS    VMwareESXHosts

[ovi-admin@liuqiong ups]$ sudo ./agent start
Starting Agent:
Done
[ovi-admin@liuqiong ups]$ ./CuiManager
CuiManager is starting...
Dell UPS Management Software - only for SNMP Device, version: 01.05.0004 2009-01
-22
Any command using option "-help" will show it's messages!!
Dell Manager>search4 -ip 172.18.127.1 -ip 172.18.127.254 -c public
Searching SNMP from 172.18.127.1 to 172.18.127.254
Start Searching Thread...
Dell Manager>Search is Completed, Found 3 UPS, Added 3 UPS
Dell Manager>list
ip          statu      model
--          -
172.18.127.75      C1K
172.18.127.24      Powerware BladeUPS
172.18.127.47      Dell UPS Rack 4200W High Efficiency Online HU - 230U
Dell Manager>_
```

Figure 123. Searching for Devices

- 4 Enter the shutdown commands (see Figure 124).


Example:


```
shutsys -ip 172.18.127.47 -e true
```

```
shutbackup -ip 172.18.127.47 -e true -m 1:00
```


```
shutfile -e true -f /opt/ups/shutdownESXi.sh -m 2
```

```
listshut -ip 172.18.127.47
```

 **NOTE:** See “Dell CUI Commands” on page 133 for a description of all Dell CUI commands.

 **NOTE:** Each guest operating system requires a minimum of 30 seconds to run the command file before shutdown. The -m 1 option in the shutfile command in the example below sets one minute as the total time allowed to run the command file before shutdown, which allows sufficient time for two guest operating systems.

Example: shutfile -e true -f /opt/ups/shutdownESXi.sh -m 1



```
etc
Exit
Exit.lax
ghettoShutdown.pl
help
lvi-admin@liuqiong ups1$ ./CuiManager
CuiManager is starting...
Dell UPS Management Software - only for SNMP Device, version: 01.05.0004 2009-01
-22
Any command using option "-help" will show it's messages!!
Dell Manager>shutsys -ip 172.18.127.47 -e true
Dell Manager>shutbackup -ip 172.18.127.47 -e true -m 1:00
Dell Manager>shutfile -e true -f /opt/ups/shutdownESXi.sh -m 2
Dell Manager>listshut -ip 172.18.127.47
172.18.127.47 Dell UPS Rack 4200W High Efficiency Online HV - 230V
Allow battery to discharge for Enable 01:00
Shut down when remaining battery time is below Disable 02:00
Begin Shutdown Immediately if Battery Low Disable
System Enable
Powered by Load Segment1
Run Command File before Shutdown Enable /opt/ups/shutdownESXi.sh
Shutdown File Max Execution Time 2 min

Dell Manager>_
```

Figure 124. Shutdown Parameters

The host server and guest operating system shut down orderly and gracefully after the battery discharges for one minute. The status is displayed in the Recent Tasks pane at the bottom of the window (see Figure 125).

Name	Target	Status	Details	Initiated by	Requested Start Time	Start Time	Completed Time
Initiated guest OS shutdown	windows2003	Completed		root	1/25/2010 2:01:37 AM	1/25/2010 2:01:37 AM	1/25/2010 2:01:37 AM
Initiated guest OS shutdown	redhat5	Completed		root	1/25/2010 2:01:07 AM	1/25/2010 2:01:07 AM	1/25/2010 2:01:07 AM
Shutdown Host	172.18.127.11	Completed		vi-admin00	1/25/2010 2:00:50 AM	1/25/2010 2:00:50 AM	1/25/2010 2:00:50 AM
Initiated guest OS shutdown	VMA4.0	Completed		root	1/25/2010 2:00:41 AM	1/25/2010 2:00:41 AM	1/25/2010 2:00:41 AM
Auto power Off		Completed		root	1/25/2010 2:00:41 AM	1/25/2010 2:00:41 AM	1/25/2010 2:00:46 AM
Shutdown Host	172.18.127.11	Completed		vi-admin00	1/25/2010 2:00:40 AM	1/25/2010 2:00:40 AM	1/25/2010 2:00:40 AM

Figure 125. Recent Tasks Pane – Shutdown Confirmation

Dell CUI Commands List

The Dell Command User Interface (CUI) is a client program that connects to the Dell Monitor Server. The program operates only on SNMP devices and is used only on operating systems that support character commands. The Dell CUI is primarily used to search for SNMP devices and to set operating system shutdown parameters. Table 4 lists the Dell CUI commands.

Table 4. Dell CUI Commands

Command	Description
del	Purpose: Delete SNMP device Format: del target_ip [[target_ip]] Example: del 172.18.128.32
help	Purpose: List all CUI commands Format: help
import	Purpose: Import batch files and execute commands Format: import target_file Example: import mybatch.txt
list	Purpose: List all SNMP devices connected to monitor Format: list
listshut	Purpose: List shutdown parameter messages Format: listshut [-ip target_ip] Option: -ip target_ip: IPv4 or IPv6 address Examples: listshut -ip 172.18.127.123 (list messages for one device) listshut (list messages for all devices)
powerby	Purpose: Show or Set message of "Powered by" Format: powerby [-ip target_ip] [-s count] Options: -ip target_ip: IPv4 or IPv6 address -s count: Segment 1 or 2 Example: powerby -ip 172.18.127.25 -s 1
quit	Purpose: Exit CUI Format: quit

Command	Description
redundant	<p>Purpose: Show, Add, or Remove IP for "Redundant UPS Input Setting"</p> <p>Format: redundant [-r] [[target_ip]]</p> <p>Option:</p> <p>-r Removes redundant SNMP devices</p> <p>Examples:</p> <p>redundant 172.18.128.32 172.18.127.50 (add redundant ip)</p> <p>redundant -r (remove all redundant ip)</p> <p>redundant (list all redundant IP messages)</p>
search4	<p>Purpose: Search IPv4 SNMP devices</p> <p>Format: search4 [ip target_ip] [-ip target_ip] [-c community]</p> <p>Options:</p> <p>-ip target_ip: IPv4 address (default is 255.255.255.255)</p> <p>-c community SNMP communication authorization (default is public)</p> <p>Examples:</p> <p>search4 -ip 172.18.127.1 -ip 172.18.127.254 -c public</p> <p>search4 (using default options value)</p>
search6	<p>Purpose: Search IPv6 SNMP devices</p> <p>Format: search6 [-ip target_ip] [-c community]</p> <p>Options:</p> <p>-ip target_ip: IPv6 address (default is ff02::1)</p> <p>-c community SNMP communication authorization (default is public)</p> <p>Examples:</p> <p>search6 -ip ff02::1 -c public</p> <p>search6 (using default option value)</p>
shutbackup	<p>Purpose: Show or Set message of "Allow battery to discharge for"</p> <p>Format: Usage: shutbackup [-ip target_ip] [-e boolean] [-m time]</p> <p>Options:</p> <p>-ip target_ip: IPv4 or IPv6 address</p> <p>-e boolean: true - enable, false - disable</p> <p>-m time: minute:second (range 0:0 - 999:59)</p> <p>NOTE No options show relative messages of device.</p> <p>Example: shutbackup -ip 172.18.127.123 -e true -m 10:10</p>

Command	Description
shutfile	<p>Purpose: Show or Set message of "Run Command File before Shutdown"</p> <p>Format: shutfile [-e boolean] [-f file] [-m time]</p> <p>Options:</p> <p>-e boolean: true - enable, false - disable.</p> <p>-f target_file: Execute file name before shutdown</p> <p>-m time: minute: (range 1 - 60)</p> <p>NOTE No options show relative messages of device.</p> <p>Example: shutfile -e true -f abc.bat -m 2</p>
shutlow	<p>Purpose: Show or Set message of "Begin Shutdown Immediately if Battery Low"</p> <p>Format: shutlow [-ip target_ip] [-e boolean]</p> <p>Options:</p> <p>-ip target_ip: IPv4 or IPv6 address</p> <p>-e boolean: true - enable, false - disable</p> <p>NOTE No options show relative messages of device.</p> <p>Example: shutlow -ip 172.18.127.123 -e true</p>
shutremain	<p>Purpose: Show or Set message of "Shut down when remaining battery time is below"</p> <p>Format: shutremain [-ip target_ip] [-e boolean] [-m time]</p> <p>Options:</p> <p>-ip target_ip: IPv4 or IPv6 address</p> <p>-e boolean: true - enable, false - disable</p> <p>-m time: minute:second (range 0:0-999:59)</p> <p>NOTE No options show relative messages of device.</p> <p>Example: shutremain -ip 172.18.127.123 -e true -m 10:10</p>
shutsys	<p>Purpose: Show or Set message of "System"</p> <p>Format: shutsys [-ip target_ip] [-e boolean]</p> <p>Options:</p> <p>-ip target_ip: IPv4 or IPv6 address.</p> <p>-e boolean: true - enable, false - disable</p> <p>NOTE No options show relative messages of device.</p> <p>Example:</p>
stopsearch	<p>Purpose: Stop searching thread</p> <p>Format: stopsearch</p>