

ALC 662 realtek HD audio on host -- no ...



[jimbo45](#) 300 posts since

May 26, 2006 Linux SUSE 10.3 host. Sound works fine. Hardware probe shows ALC 662 realtek HD audio although Linux is using the Intel Hd driver.

Guest XP PRO system sound icon appears and volume control etc works fine -- but NOT A SQUEAK of physical sound appears.

Host sound working 100% perfectly.

Workstation version 6.03

cheers

-j