


Dell MD3000i Cabling Diagram

- iSCSI
- Server LAN
- Up-Link Port



Service Console	10.###.###.196	vmnic0 (SW1) & vmnic4 (SW2)
VMKernel	10.###.###.197	vmnic0 (SW1) & vmnic4 (SW2)
VM Network		vmnic1 (SW1) & vmnic5 (SW2)
iSCSI VMKernel	172.16.100.1	vmnic2 (SW1) & vmnic3 (SW2)
Service Console 2	172.16.100.51	vmnic2 (SW1) & vmnic3 (SW2)

Service Console	10.###.###.198	vmnic0 (SW2) & vmnic4 (SW1)
VMKernel	10.###.###.199	vmnic0 (SW2) & vmnic4 (SW1)
VM Network		vmnic1 (SW2) & vmnic5 (SW1)
iSCSI VMKernel	172.16.200.1	vmnic2 (SW1) & vmnic3 (SW2)
Service Console 2	172.16.200.51	vmnic2 (SW1) & vmnic3 (SW2)